

Scheiben für Schäffer-Kabinen

	Front	Seite	Tür	Heck	Dach	sonstige
Kabine 450T <i>61370</i>	613702101	613703105	613704104 613704105	613705109	613706380	
Kabine 550T <i>61372</i>	613722101	613723105	613724104 613724105	613725109	613726380	548
Kabine 870T <i>61371</i>	613712101	613713105	613714104 613714105	613715109	613716380	
Kabine 3036 <i>61373</i>	613732101	613733105	613734104 ✓ 613734105 H	613735109	613736380	
Kabine 5058 <i>61375</i>	613752101	613753105	613754103 613754104	613755109	613756110	
Kabine 8082 <i>61376</i>	613762101	613763105	613764104 613764105	613765109	613766110	
Kabine 450T-02 / 4042 <i>61377</i>	613772101	613733105	613734104 613734105	613775109	613736380	
Kabine HL 2033 <i>61362</i>	613622101	613623105	613624104 613624105	613625109	613736380	
Kabine 980T	613632101	613633105	613634104 613634105	613635109	613756110	
Schutzrahmen 3036	613612101	xxxxxx	xxxxxx	613735109	613736380	
Schutzrahmen 450T-02	613782101	xxxxxx	xxxxxx	613775109	613736380	
Schutzrahmen 5058	613792101	xxxxxx	xxxxxx	613755109	613756110	